

Fortezza da Basso • FLORENCE (Italy)

30th September • 2nd October 2019

The Path Forward for Pipe Bursting Asbestos
Cement Pipe in the US

Edward Alan Ambler, PE, LEED AP AM Trenchless


PIPE BURSTING DEFINITION




- Pipe bursting is defined as a trenchless replacement method in which an existing pipe is fractured in place, and a new pipe with the same or larger ID is pulled into its place. The pipe bursting process uses energy from a cable or rod pulling system, hydraulic or pneumatic power. This energy is transmitted to the expander or pneumatic hammer to burst the existing pipe and temporarily expand the soil cavity surrounding the existing pipe.
- Three things are happening simultaneously
 - (A) the existing pipe is being fractured or split
 - (B) the soil is being expanded to receive the new pipe
 - (C) the new pipe is being pulled into the place of the existing pipe.

PIPE BURSTING – PNEUMATIC AND STATIC







Range of Diameters and Lengths

- Typical range of diameters up to 54" but typically used for pipes smaller than 36"
- The majority of pipe bursting projects are between 6" and 12"
- Typical lengths of pipe bursting runs are between 300' and 500'
- Production levels are affected by the number of required excavations
- Much longer lengths of pipe bursting runs have been performed but take longer
- Pipe bursting typically can not pull through manufactured bends (greater than 22 degrees), valves and tees








PIPE BURSTING VS. OPEN CUT

- Reduced carbon emissions
- Protection of the environment, trees, landscaping, and other natural ecosystems, particularly developed urban and suburban environments
- New line does not occupy new space in the right-of-way
- Reduced traffic impacts
- Reduction in damage prevention to thirdparty utilities
- Substantially reduced amount of excavation









History of Asbestos



Naturally occurring mineral fiber Attractive attributes

- Fire and chemical resistance
- •Flexible, long, thin fibrous shape
- High strength

Use noted as early as Ancient Greece

Use of asbestos supported nationwide during the early 20th century

US Navy was #1 consumer of asbestos during the first half of the 20th century


Knowledge of inhalation dangers solidified by 1950's



AWWA Work Practices for AC Pipe



- Keep the AC pipe wet
- Don't saw cut the AC pipe to release fibers
- Utilize a snap cutter on the AC pipe



Asbestos Fibers During Rehabilitation

- Work during a multiple recent pipe bursting projects in the United States performed an extensive Negative Exposure Assessment on the pipe bursting project
- Results indicated levels of asbestos under the limits set by US Occupational Safety and Health Administration
- 0.1 fibers per cubic centimeter of air





Is AC Pipe Friable After Bursting?



- <u>US EPA</u> currently believes AC pipe that has undergone the mechanical process of pipe bursting <u>SHOULD BE SUBJECT TO</u> NESHAP.
- RACM is defined as friable asbestos
 material or non-friable ACM that will be or
 has been subjected to sanding, grinding,
 cutting, or abrading or has crumbled, or
 been pulverized or reduced to powder in the
 course of demolition or renovation
 operations



RACM is regulated AC pipe that can be further reduced to powder by hand

NATIONAL EMISSIONS STANDARDS FOR HAZARDOUS AIR POLLUTANTS



- Promulgated in 1972
- Part 61 governs 7 key air pollutants
 - Asbestos, Beryllium, Mercury, Vinyl Chloride, Benzene, Arsenic, Radon/radionuclides
- Requires an Act of Congress to change
- Does not provide adaption for technology development
- Does allow for an Administrator Approved Alternate as approved process different from regulations

- **NESHAP COMPLIANCE 5 KEY STEPS**
- Notice Submit 10 days prior to work (61.145(b))
- Emission Control during work (61.145(c) / 61.150)
- Control Public Access 2' of cover or fencing (61.151 / 61.154)
- Deed Notation for site after work is complete (61.151(e))
- Notice Prior to Digging Up Site 45 days before digging up the site (61.154(j) / 61.1(d))






	F DE	'ROJECT (CHECK ONE ONLY): :MOLITION, IS IT AN ORDERED D :NOVATION:		LITION?	☐ REN		NO NO					
		IS IT AN EMERGENCY RENOVAT IS IT A PLANNED RENOVATION O			□YES □YES		NO NO					
F	acilli	y Name <u>City of Casselberry Potab</u>	le Wa	ter System								
ddre	ss <u>Pr</u>	oject Area 12 (Helen St, Timberlar	ne Tra	all, Landmark Ln, L	ands End,	Colo	ny Dr. Au	rora Dr, Belle Ave) - Exhibit /	A		
tly <u>Casselberry</u> State <u>FL</u> Zip <u>32707</u> Countly <u>Seminole</u>												
tlePublic Road Right-of-Way (as stated above) see attachment - Exhibit A Consultant Inspecting Site CPH Engineers												
uilding Size NA (watermain) (Square Feet) # of Floors Building Age in Years 50												
rior Use: School/College/University Residence Small Business Other potable water distribution system												
reser	nt Us	e: School/College/University		esidence Sm	all Busines	SS	○ Other	potable water dist	ribution sys	tem		
Facility Owner City of Casselberry Phone (407) 262-7725												
ddress 95 Triplet Lake Drive												
		berry		State FL				Zip <u>3270</u>	07		_	
		actor's Name Killebrew. Inc.					Phone (86	3) 701-0273				
	_	O. Box 6258										
	akela		_	State FL	_	17		p <u>33807</u>				
		actor exempt from licensure under				_	YES	□ NO				
		fuled Dates: (Notice must be postr							naa allaabaa		Dubbi D	
		lemoval (mm/dd/yy) Start: see attachment - Exhibit B		Finish:	_ Demo	Heri	wauon (n	nm/dd/yy) Start:	see allacilli	nerit -	EXTIDILE	
			ovati	on work to be perfo	med and	met	ods to be	employed, includi	na demolitic	on or	renovation tech	niques
 Description of planned demoition or renovation work to be performed and methods to be employed, including demoition or renovation techniques be used and description of affected facility components, pipe bursting to replace existing asbestos-cementitious water main 												
Procedures to be Used (Check All That Apply):												
		Olds and Daniel		Olessa Base						ПП	Wrecking Bal	
		Strip and Removal		Glove Bag			Bulldaze	er			WICKING Dal	
		Wet Method	片	Dry Method		H	Explode			╁	Burn Down	_
	1			•							0	\vdash
	1	Wet Method		•						Ö	0	
	OTI	Wet Method		Dry Method	P					<u> </u>	0	
	OTI	Wet Method HER:pipe bursting	op w	Dry Method			Explode	9	58		0	
II. A	OTI	Wet Method HER:pipe bursting dures for Unexpected RACM: St	op w	Dry Method			Explode	9	58		0	
II. <i>I</i> ddre	OTI	Wet Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034	op w	Dry Method		f rea	Explode	9		p <u>338</u>	Burn Down	
II. <i>I</i> ddrei ity <u>L</u>	roce Asbe	Wet Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034	top w	Dry Method ork and notify FDE a Constr. & Enviro		f rea	Explode	9			Burn Down	
II. <i>I</i> ddrei ity <u>L</u> III. V	roce Asbe	Wei Method HER:pipe bursting dures for Unexpecied RACM: Si stos Wasie Transporier: Name O. Box 90034 und	top w	Dry Method ork and notify FDE a Constr. & Enviro		f rea	Explode	none (<u>963)</u> 284-09			Burn Down	
II. A ddrei ity <u>L</u> III. V ddrei	roce Asbe	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Wasie Transporter: Name O. Box 90034 Ind Disposal Site: Name Angelo's Re 1111 Enlerprise Road	top w	Dry Method ork and notify FDE a Constr. & Enviro		f regi	Explode	none (<u>963)</u> 284-09	z		Burn Down	
II. Addreson the state of the s	OTT roce Asbe ss P akels /aste	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Wasie Transporter: Name O. Box 90034 Ind Disposal Site: Name Angelo's Re 1111 Enlerprise Road	lop w	Dry Method ork and notity FDE a Constr. & Enviro	nmental (I	Sta	Explode d) Pr the FL of the FL	onone (<u>863) 294-09</u> Diass <u>III</u>	z	ip <u>338</u>	Burn Down	
ddrei ity <u>L</u> III. V ddrei ity <u>C</u>	OTI Asbe as P akela Vaste as 4:	Wei Method HER:pipe bursting dures for Unexpecied RACM: Si stos Wasie Transporijer: Name O. Box 90034 ind Olsposal Sitie: Name Angelo's Re Intil Enterprise Road City	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	nmental (I	Sta	Explode d) Pr the FL of the FL	onone (<u>863) 294-09</u> Diass <u>III</u>	z	ip <u>338</u>	Burn Down	
ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R	roce Asber as P akela Vaste as 4: ade	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Waste Transporter: Name O. Box 90034 ind Disposal Site: Name Angelo's Re 1111 Enterprise Road City or ACM: Procedure, including an asbestos-cementillious pile (caled)	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	nmental (ii	Sta	Explode Explode Explode Explode Explode Explode Explose Explo	onone (<u>863) 294-09</u> Diass <u>III</u>	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R	on oce as Pakels Vaste ss 4: ade vaste state vaste state vaste state vaste state vaste state vaste state sta	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 9034 ind Disposal Site: Name Angelo's Re 1111 Enterprise Road City or ACM: Procedure, including an	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to det	Sta	Explode Explode Photo FL Coulte FL Country FL Cou	none (863) 284-09 Diass III Dias III Dias III Dias III	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. A ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R resur	OTTOCE Asbe Asbe akels Askels Askels ACM med i	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name 0. Box 90034 Ind Olsposal Site: Name Angeto's Re 1111 Enterprise Road City or ACM: Procedure, including an asbestos-cementificus pilce (calego RACM or ACM"	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to det	_Sta	Explode d) Pr ste FL co co co co co co co co co c	none (863) 284-09 Class III Class II	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. A ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R resur	OTTOCE Asber akelass P akelasse Aster Acommed a	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034 Ind 10 Disposal Sitje: Name Angelo's Re 1111 Enterprise Road City I or ACM: Procedure, including an asbestice cementillious pipe (caleox ACM or ACM' are feet surfacing malerial	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to det	_Sta	Explode d) Pr ste FL co co co co co co co co co c	none (863) 284-09 Diass III Dias III Dias III Dias III	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. A ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R resur	OTTOCE Asbee Asbee Asbee Askels Asses Asse	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Waste Transporter: Name O. Box 90034 Ind Disposal Site: Name Angelo's Re 1111 Enterprise Road City for ACM: Procedure, including an asbestoe-cementitious pipe (calego AACM or ACM* are teet surfacing malerial ar feet pipe	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to det X. Fi Cit	_Sta	Explode And Photo FL Case FL Control FL	none (863) 284-09 Diass III Diass II	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. A ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R resur	OTTOCE Asber Asber Asber Asber Askels Askels AcM med s t of F squ line cub	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034 und Olsposal Site: Name Angelo's Re 1111 Enterprise Road City or ACM: Procedure, Including an asbestice-cementificus pilce (caleox AACM or ACM" are feet surfacing malerial ar feet pipe to teet of PACM of facility compon	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to deli X. Fr Cit Pul	_ Sta _ Sta _ Sta _ ect tr _ y of blic _ Trip	Explode d) Pr de FL cote FL expressed Cassellt Works I	chone (<u>B63</u>) <u>284-09</u> Class III Due of RACM and C II Be Sent to Addin Derry Department a Drive	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. A ddrei tty <u>L</u> III. V ddrei tty <u>C</u> C R resur	OTTOCE Asber askels Askels Activities Activities Cub squ squ	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034 Ind O. Box 90034 Ind O Box 90034 Int Interprise Road Int Interprise Road Int O ACM: Procedure, including an asbestice-cementillious pipe (caleo: ACM or ACM' are feet surfacing material ar feet pipe Icreet of PACM of Tacility componere feet cementitious material	Lenor	Dry Method ork and notity FDE: a Constr. & Enviro ng (if required) sal methods, emplo	yed to deli X. Fr Cit Pul	_ Sta _ Sta _ Sta _ ect tr _ y of blic _ Trip	Explode d) Pr de FL cote FL expressed Cassellt Works I	none (863) 284-09 Diass III Diass II	Zi Zi atlegory I ar	ip <u>338</u>	Burn Down	
II. Addressity L. III. V dddressity C. Fressit mour	OTTOCE Asbee Asbee Asbee Asbee Askels Askels Askels Ack Ack Incl Incl Squ Incl Squ Squ Squ	Wei Method HER:pipe bursting dures for Unexpected RACM: Si stos Wase Transporter: Name 0. Box 90034 Ind Obsposal Site: Name Angelo's Re 1111 Enterprise Road City or ACM: Procedure, Including an asbestos-cementificus pilee (caleous PACM or ACM' are feet surfacing material ar feet pipe to feet of PACM off facility compon are feet cementitious material are feet resilient flooring are feet esphalt rooting are feet asphalt rooting	Lenor Lenor	Dry Method ork and notify FDE: a Constr. & Enviro ng (If required) sal methods, emplo nonfriable)	yed to del X. Fo Cit Pul 95	_sta _sta _sta _sta _sta _sta _sta _sta	Explode the FL could be FL co	connoce (<u>863</u>) <u>284-09</u> Class <u>III</u> Coe of RACM and C II Be Sent to Adda Derry Department 9 Drive	zi zialegory I ar	ip 338 ip 322 nd II r	Burn Down	
III. Jaddreity L. Ville V. Vil	OTTOCE Asbee Asbee Asbee Asbee Askels Askels Asses A: ACM Ined: Squ Ine Squ	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Waste Transporter: Name O. Box 90034 ind Disposal Site: Name Angelo's Re 1111 Enterprise Road City or ACM: Procedure, including an asbestos-cementitious piloe (caleot AACM or ACM* are feet surfacing material ar feet pipe to teet of FACM off facility compon are feet cementitious material are feet resilient flooring	Lenor lecycle and the control lecycle lecycle lecycle lecycle lenor lecycle lecycle lenor lecycle lenor lecycle lenor le	Dry Method ork and notity FDE a Constr. & Enviro ng (If required) sal methods, emplo nonfriable)	yed to dell X. Fi Cit. Pul 95 Ca	_ State _ Stat	Explode d) Ph the FL counter Elements works I liet Lake berry, F CM is exi	connoise (863) 284-09 Class III	zi alegory I ar	ip 338 ip 322 nd II r	Burn Down	
III. A ddre tity L III. V ddre tity C F resu mour 365'	OTTOCE Asbee Asbee Asses Askels Asses ACM Med Ine Squ	Wet Method HER:pipe bursting dures for Unexpected RACM: Si stos Waste Transporter: Name O. Box 90034 Ind OBsposal Site: Name Angelo's Re Ind OBsposal Site: Name Angelo's Re Ind OBsposal Site: Name (Induding an asbestos cementiflous pipe (celeor AACM or ACM* are teel surfacing malerial ar feet pipe to feet of PACM off facility compon are feet comentiflous malerial are feet resilient flooring are feet asphalt roofing d describe surfacing malerial and of	Lenor	Dry Method ork and notify FDE: a Constr. & Enviro ng (if required) sal methods, emplo nonfriable) materials as applic blaced with high de at an individual trai	yed to det X. Fr Cit. Pui 95 Ca able: None	State	Explode d) Ph the FL country FL countr	chone (<u>B63</u>) <u>284-09</u> Class <u>III</u> Doe of PACM and C II Be Sent to Addin Derry Department Departm	Zialegory I ar	ip 338 ip 338 ip 322 ip	Burn Down 1005 1005 1006 1008: (Print or 1) 1008: (Print or 1) 1008: (Print or 1)	Type)
III. Juddred the control of the cont	OTTOCE Asbee ass Pakels Asses	Wet Method HER:pipe bursting dures for Unexpected RACM: St stos Waste Transporter: Name O. Box 90034 Ind O. Box 90034 Ind O Box 90034 Ind O Box 90034 Ind O Box 90034 Ind O RACM: Procedure, including an asbestice cemertillious pipe (caleo: ACM or ACM') are feet surfacing material ar feet pipe Ic feet of RACM off facility compon are feet cementillious material are feet resilient flooring are feet surfacing material and of dusing pipe bursting lechnology are the above information is correct as the devider of which the surfacing material and of dusing pipe bursting lechnology are the above information is correct as femolution or renovation and evider surfacing material and of dusing pipe bursting lechnology are the above information is correct as femolution or renovation and evider surfacing material and of dusing pipe bursting lechnology are the above information is correct as femolution or renovation and evider surface and evider	Lenor	Dry Method ork and notify FDE: a Constr. & Enviro ng (if required) sal methods, emplo nonfriable) materials as applic blaced with high de at an individual trai	yed to det X. Fr Cit. Pui 95 Ca able: None	State	Explode d) Pr color of the FL color o	chone (<u>B63</u>) <u>284-09</u> Class <u>III</u> Doe of PACM and C II Be Sent to Addin Derry Department Departm	Zialegory I ar	ip 338 ip 338 ip 322 ip	Burn Down 1005 1005 1006 1008: (Print or 1) 1008: (Print or 1) 1008: (Print or 1)	Type)
III. Juddressity L. Verseumour 365'	OTTOCE Asbet Asbet Asset Askels Asset Acade Acade Inec cub squ squ ytal the c i bus Name	Wet Method HER:pipe bursting dures for Unexpected RACM: SI stos Waste Transporter: Name O. Box 90034 Ind O. Box 90034 Ind O Box 90034 Int Interprise Road Int Interprise Road Int Interprise Road Int ACM: Procedure, including an asbestice-cementillious pipe (caleo: ACM or ACM') are feet surfacing material ar feet pipe ic feet of PACM off facility compon are feet cementitious material are feet resilient flooring are feet surfacing material and of dusing pipe bursting technology are the above information is correct at semotion or renovation and evider ness hours.	Lenor	Dry Method ork and notify FDE: a Constr. & Enviro ng (if required) sal methods, emplo nonfriable) materials as applic blaced with high de at an individual trai	yed to det X. Fr Cit. Pui 95 Ca able: None	_ State of the sta	Explode Explode Explode Explode Explore Exp	chone (<u>B63</u>) <u>284-09</u> Class <u>III</u> Doe of PACM and C II Be Sent to Addin Derry Department Departm	Zialegory I ar	ip 338 ip 338 ip 322 ip	Burn Down 1005 1005 1006 1008: (Print or 1) 1008: (Print or 1) 1008: (Print or 1)	Type)

WRF #4465 - PROJECT OVERVIEW





Objectives:

- 1. Synthesize existing knowledge on AC pipe renewal.
- 2. Demonstrate technologies to gather environmental impact data.
- 3. Inform the stakeholder groups of project findings.








Environmental Impact of Asbestos Cement Pipe Renewal Technologies

Web Report #4465



ENVIRONMENTAL IMPACT OF AC PIPE BURSTING – WRF PROJECT #4465



There is no evidence to support that the bursting of AC pipe has any negative impacts on the environment or the workers performing the work

Sample Type	No. of Samples	Analytical Sensitivity Range	Sample Result Range	Analytical Method	
Air	6	0.0036 - 0.0042 s/cc	BAS	ISO Method 10312	
Soil			ND - Trace (<0.25% visual		
(Pre-renewal)	6	NA	estimate)	EPA Method 600/R-	
Soil			ND - Trace (<0.25% visual	93/116	
(Post-renewal)	6	NA	estimate)		
Water		0.17 - 0.35 million	0.87 - 20.07 million		
(Pre-renewal)	2	structure/L	structure/L	EPA Method 100.2	
Water		0.08 - 0.09 million	0.09 - 0.94 million	EPA Memod 100.2	
(Post-renewal)	2	structure/L	structure/L		

MITIGATION OF EXPOSURE RISK UTILITY CROSSINGS



- Occur when other utility companies are required to perform work around remaining AC pipe fragments
- Utility companies will not perform extensive excavation within a few inches of the new HDPE pipe

The reality is - all work performed will be below the 260 linear feet threshold set forth by NESHAP

MITIGATION OF EXPOSURE RISK RESIDENT EXCAVATION



- Resident installing new tree or other will not excavate to water main depth for extended length
- Casselberry utilizes special locate flags that will generate questions

The reality is - all work performed will be below the 260 linear feet threshold set forth by NESHAP



MITIGATION OF EXPOSURE RISK REPLACEMENT OF PIPE



- Utility provider performing AC pipe bursting must acknowledge the risk of future work required around AC pipe fragments
- Emergency repairs will be below the 260 linear feet threshold set forth by NESHAP
- Focused production pipe replacement will occur after production pipe has expelled its service life

The reality is - all work performed will be below the 260 linear feet threshold set forth by NESHAP

RESISTANCE TO AC PIPE BURSTING



- AC pipe bursting projects can only be performed with all parties acknowledgement of process
- Right-of-way controllers approval
 - Casselberry only owns R/W for 30% of streets where AC pipe is located
- Local Environmental Regulators approval
- General public approval


RESISTANCE TO AC PIPE BURSTING UNCLEAR APPLICATION OF NESHAP



- Active Hazardous Waste Site
 - One year of air monitoring
 - Signs above site every several hundred feet
- In-active Hazardous Waste Site
 - Record notation to deed to property
 - Problem: Public right-of-way has no deed
 - After significant discussion and demonstration of pipe bursting,
 EPA suggested use of the Administrator Approved Alternate

RESISTANCE TO AC PIPE BURSTING ACTIVE HAZARDOUS WASTE SITES






RESISTANCE TO AC PIPE BURSTING PIPE BURSTING SITES











EDWARD ALAN AMBLER, PE, LEED AP AM TRENCHLESS